

Includes: broom, mop, duster, dust pan, spray bottle, cleaning cloth, and sponge.

LET'S ASSEMBLE!

The mop, broom, and duster extend so they grow with your lil helper.



Please read thoroughly, assemble, and make height adjustments to toys prior to giving them to your child.

Broom

- To assemble the broom, simply screw the end of the shaft into the head of the broom.
- To adjust the broom, twist the locking mechanism on the shaft counter-clockwise to loosen. Pull the handle to the desired length and twist the locking mechanism clockwise to lock into place.

Mop

1. To assemble mop, insert head into shaft base.
2. Next, insert pins through opening in shaft and press tightly until they snap into place.



- To adjust the mop height, twist the locking mechanism on the shaft counter-clockwise to loosen. Pull the handle to the desired length and twist the locking mechanism clockwise to lock into place.

Retain this information for future reference.

Spray Bottle

- This is a fully-functioning spray bottle, so open and fill as you would any other spray bottle by twisting the base of the spray head and removing it to fill.
- Only fill the spray bottle with water.

Hand Duster

- No assembly required! Just pull on the handle to the desired length.

HOW TO CARE

These tools will see a lot of play, so they'll need to be cleaned. Here's how you keep the cleaning tools in tip top shape.

- Any plastic tools or parts can be washed and/or wiped clean with a damp cloth.
- Any fabric elements can be hand washed and air dried.

HOW TO PLAY SAFE

Play time is at its best when playing it safe.

- Remove all packaging materials and assemble all necessary components prior to giving the cleaning set to your child(ren).
- Always supervise child(ren) during play.

WARNING:
CHOKING HAZARD - Small parts.
Not for children under 3 yrs.